

IT Deployment RunBook

i Audience: IT administrators and DevOps engineers deploying the product in enterprise environments (Windows Server, on-premises, or private cloud). This page is an operational workflow — install, configure, monitor, update, secure. For deep product reference, each section links to the corresponding technical page.

What You'll Deploy

A typical enterprise deployment has three layers:

- **Runtime server** — one Windows Server machine that runs the solution (tags, alarms, historian, scripts) as a Windows Service. This is the core of any deployment.
- **Client stations** — operator workstations running the Rich Client (WPF), or users accessing the solution through web browsers (HTML5 /WebAssembly).
- **Integration points** — PLCs, databases (SQL Server, Oracle, PostgreSQL), historian storage, and optionally MQTT brokers, OPC UA servers, or cloud endpoints.

For architecture context and sizing, see [Platform Architecture Reference](#) and [Deployment Scenarios](#).

Other deployment modes (Linux, Docker/Kubernetes, edge devices, mobile clients) are supported but outside the scope of this runbook. See the links in section 10 below.

1. Plan

Before installing, decide:

- **Runtime placement** — dedicated server (recommended) or shared application server. The runtime is a single executable plus supporting services.
- **Service account** — a domain service account (preferred) or Local System. Domain accounts allow auditing and controlled access to network resources, databases, and file shares.
- **Historian database** — built-in SQLite (small deployments), external SQL Server / PostgreSQL / Oracle (typical), or time-series databases (InfluxDB, TimescaleDB).
- **Ports and firewall** — see the Network Ports section below. Open only what you need, inbound only where required.
- **License model** — per-server licensing with online or offline activation. See [Licensing Procedures Reference](#).
- **High availability** — optional runtime redundancy (primary/secondary). See [Redundancy Reference](#).

2. Install

Prerequisites

- Windows Server 2019 or later (Windows 10 / 11 for small deployments)
- .NET Framework 4.8 (included in Windows 10+)
- .NET 8 runtime (required for cross-platform runtime, AI integration, and DataHub)
- Visual C++ 2015-2022 Redistributable (bundled with the installer)
- Administrator rights on the target machine

Interactive install

Run the signed installer and follow the wizard. Default install location is C:\Program Files\Tatsoft\FrameworX\. Full step-by-step reference: [Installation and Licensing Reference](#).

Silent / unattended install

The installer is an Inno Setup package and supports standard silent switches for SCCM, Intune, PowerShell DSC, Ansible, or any deployment pipeline:

```
Start-Process -FilePath "FrameworX-10.1.5-Setup.exe" `
-ArgumentList "/VERYSILENT", "/SUPPRESSMSGBOXES", "/NORESTART", `
              "/LOG=C:\Logs\frameworx-install.log", `
              "/DIR=C:\Program Files\Tatsoft\FrameworX" `
-Wait -PassThru
```

Common switches:

Switch	Purpose
/VERYSILENT	Fully silent — no progress, no prompts

/SUPPRESSMSGBOXES	Suppress all message boxes (use with /VERYSILENT)
/NORESTART	Prevent automatic reboot on completion
/DIR="<path>"	Override default install directory
/LOG="<path>"	Write install log to specified file

Install exit codes:

Code	Meaning
0	Success
1	Setup failed to initialize or user aborted
2	User cancelled during preparation
5	Install aborted (user cancelled during copy)
3010	Success — reboot required to complete

File-copy install (.NET 8 runtime only)

The .NET 8 runtime can also be deployed by copying the installation folder. Useful for portable deployments, custom update pipelines, and locked-down environments where MSI-style installs are blocked. See [Runtime Installation Reference](#).

3. Configure

Install folders

Standard install layout:

Location	Purpose
C:\Program Files\Tatsoft\FrameworX\	Executables and supporting libraries (read-only after install)
C:\Users\Public\Documents\FrameworX\	User-facing content: solutions, exchange folder, screenshots, trace logs (default)
C:\ProgramData\Tatsoft\FrameworX\	Optional location for operational data when configured for enterprise deployments

Full layout reference: [Installation Folders and Utilities Reference](#).

Run the runtime as a Windows Service

For production, the runtime should run as a Windows Service so it starts automatically with the machine, survives user logouts, and is managed through standard Windows tooling (sc.exe, Services.msc, Get-Service).

Service install options:

- **Designer UI** — Runtime Startup has an AutoStartup button that installs the runtime as a Windows Service
- **Command-line** — use TManageServices.exe (located in the product root folder) from an elevated shell

Example: install the runtime as a Windows Service for a specific solution, unattended:

```
cd "C:\Program Files\Tatsoft\FrameworX"
.\TManageServices.exe /installtstartup `
  /solution:"C:\Users\Public\Documents\FrameworX\Solutions\Plant1.tproj" `
  /silent

# Uninstall later
.\TManageServices.exe /uninstalltstartup /solution:"Plant1" /silent
```

TManageServices.exe also handles TWebServices, TSecureGateway, TMQTTBroker, THardkey, and RuntimeMCPHttp. Run TManageServices.exe /? for the full command list. The /silent flag makes it script-friendly: it never pauses for input and returns a non-zero exit code on failure. Full reference: [Runtime Startup Reference](#).

Run the service under a dedicated domain account where possible. The account needs:

- Log on as a service
- Read access to the solution folder
- Write access to log and data directories
- Network access to PLCs, databases, MQTT brokers, and OPC UA servers as required by the solution

Web server configuration

Web client, REST endpoints, and runtime HTTP services are hosted by the built-in web server. Configure ports, TLS certificates, and optional reverse-proxy routing as described in [Web Server Configuration Reference](#).

Licensing

Online activation is used for internet-connected servers. Offline activation (license file transfer) is supported for air-gapped networks. See [Licensing Procedures Reference](#).

Network ports

Typical enterprise deployment ports:

Port	Protocol	Service	Direction
3101	TCP	Runtime client-server	Inbound from Rich Clients
3110	HTTP	Web client (non-TLS)	Inbound from browsers
3111	HTTPS	Web client (TLS)	Inbound from browsers
4840	TCP	OPC UA Server (optional)	Inbound from OPC clients
1883 / 8883	TCP / TLS	MQTT broker (optional)	Inbound from MQTT clients
1433 / 5432 / 1521	TCP	SQL Server / PostgreSQL / Oracle	Outbound from runtime to DB

Default runtime and web ports are configurable. Exact values depend on solution configuration — see [Runtime Startup Reference](#) and [Server Configuration Reference](#).

4. Monitor

Log locations

The runtime writes trace logs by default to `C:\Users\Public\Documents\FrameworX\TraceLogs\`. The location is configurable per solution via Solution Settings; enterprise deployments typically relocate it under ProgramData so it's picked up by Windows-standard log collectors (Splunk forwarder, Datadog agent, Azure Monitor, ELK).

Install logs are written to the path specified by `/LOG=` during silent install, or to `%TEMP%\Setup Log YYYY-MM-DD.txt` for interactive installs.

Service lifecycle events

Windows logs basic service start, stop, and unexpected termination events for every installed FrameworX Windows service to the **System** event log under source `Service Control Manager`. SCOM, Azure Monitor, Datadog, PRTG, and other Windows-native monitoring tools pick these up automatically without any custom configuration — point your alerts at the service name (for example, `TStartup-<SolutionName>`).

Application-level events (solution load failures, license errors, module exceptions) are written to the runtime TraceLogs. When an Event Log entry indicates a service failed to start, the root cause detail is in the most recent TraceLog file.

Runtime System Monitor

The built-in System Monitor exposes live metrics on tags, modules, memory, and client sessions. See [Runtime System Monitor Reference](#) and [Runtime Diagnostics Reference](#).

5. Update & Rollback

Updates within the same major version (e.g. 10.1.5 to 10.1.6) can be applied by running the newer installer over an existing installation. The installer supports side-by-side versioning with rotation, so a minor update can be rolled back by re-running the previous installer. Full semantics: [Managing Updates and Multiple Versions Reference](#).

Before updating a production server:

- Back up the solution folder (`C:\Users\Public\Documents\FrameworX\Solutions\`)
- Back up the historian database (if external)
- Stop the runtime service gracefully
- Run the installer with silent switches
- Start the service and verify via System Monitor and the Windows System event log

6. Uninstall

Uninstall from Programs & Features or silently:

```
"C:\Program Files\Tatsoft\FrameworX\unins000.exe" /VERYSILENT /SUPPRESSMSGBOXES /NORESTART
```

The uninstaller removes the installed executables, the Windows Service registration, and the registry entries. User content under C:\Users\Public\Documents\FrameworX\ is preserved — remove manually if you want a fully clean uninstall.

To remove **only** the installed Windows services (without removing the product files), use:

```
cd "C:\Program Files\Tatsoft\FrameworX"  
.\TManageServices.exe /removeallservices /silent
```

7. Secure

Production deployments should follow the hardening checklist. Topics include TLS configuration, authentication (local users, Windows authentication, Active Directory), role-based access control, secrets storage, audit logging, and network segmentation.

- [Security Hardening Reference](#) — detailed procedures
- [Security Hardening Compliance How-to](#) — step-by-step hardening guide
- [IEC 62443 Compliance How-to](#) — industrial cybersecurity standard
- [NERC-CIP Compliance How-to](#) — critical infrastructure
- [FDA 21 CFR 11 Compliance How-to](#) — regulated industries

8. Automate

Typical automation patterns:

- **SCCM / Intune** — package the silent installer as an application deployment with the switches shown in section 2. Use exit code 3010 as a soft-reboot signal.
- **PowerShell DSC / Ansible / Chef** — wrap Start-Process with the silent switches and check exit codes for the product installer; use TManageServices.exe /silent for service install/uninstall steps.
- **Solution deployment** — copy the .dbsln solution file to the target server's Solutions folder, then run TManageServices.exe /installstartup /solution:"<path>" /silent to install the runtime as a service. Solutions are self-contained.
- **Bulk uninstall** — call unins000.exe with silent switches across a fleet, or TManageServices.exe /removeallservices /silent to clean services only.

9. Troubleshoot

Symptom	First place to look
Service won't start	Windows System event log (source Service Control Manager) for the service start failure; then open the most recent file in the TraceLogs folder for application-level detail
Port conflict	netstat -ano to find what's on the port; change port in Runtime Startup config
License error	Runtime TraceLogs for the detailed license error, then Licensing Procedures Reference
Client can't connect to runtime	Firewall rule on runtime port, Test-NetConnection from client, runtime client-server logs
Web client blank / auth error	TLS certificate validity, browser console, Web Server Configuration Reference
Database connection fails	Service account permissions, connection string, firewall rule to DB server

Deep reference: [Runtime Troubleshooting Reference](#).

When opening a support ticket, collect: the most recent TraceLog file, the install log, the output of Get-Service for the runtime service, the relevant Windows System event log entries for the service, and the solution build number.

10. Other Deployment Modes

This runbook focuses on typical enterprise Windows Server deployments. Other modes are supported — see the dedicated references:

- [Container Deployment Reference](#) — Docker and Kubernetes
- [Linux Deployment Reference](#) — .NET 8 on Linux servers and edge devices
- [Redundancy Reference](#) — primary/secondary runtime pairs
- [SecureGateway Services Reference](#) — multi-site communication routing
- [Mobile App](#) — mobile client deployment

11. Remote management via SolutionCenter API

From 10.1.5 GA, the recommended pattern for managing many FrameworkX installations from a central place is the **SolutionCenter API** — a JWT-authenticated REST surface that every installation exposes on port 10108 (TWebServices). Central tools call it directly; bulk fan-out happens at the orchestration layer (Ansible, PowerShell DSC, custom dashboards) rather than per-machine WinRM or shipped agents. Surface covers solution lifecycle (list/run/stop), file ops, license activation, machine settings, and runtime connection inspection.

Activation-gated **default-OFF** in 10.1.5 — operators must explicitly enable per installation; see [SolutionCenter API Reference](#) for the activation procedure, scope model, endpoint catalog, and OpenAPI 3.1 document URL.

The product-install-time and service-lifecycle patterns from sections **2** and **8** above (silent installer, TManageServices.exe, SCCM / Intune / PowerShell DSC) are still the right tools for the install + service-registration layer of a fleet rollout. The SolutionCenter API operates one layer above — once installations exist, it manages what runs on them.